

# ACCESSORI ACCESSORIES ACCESSOIRES



OVOLUX MOUNTING ADAPTER


## OVOLUX MOUNTING ADAPTER

ADATTATORE (necessario per utilizzare gli accessori)  
ADAPTER (to mount the accessories)  
ADAPTATEUR (nécessaire pour utiliser les accessoires)

Codici / Codes

OVOLUX MOUNTING ADAPTER

27697



EXTENDED FOOT L10


## EXTENDED FOOT L10

Base piana per montaggio superficiale con estensione di 10 cm  
Flat base for surface mount with 10 cm extension  
Base pour montage à plat (position soulevée de 10 cm)

Codici / Codes

EXTENDED FOOT L10

27764



WALL MOUNT


## WALL MOUNT

Base parete per montaggio laterale  
Wall base for side mount  
Support fixation en applique (à filetage simple)

Codici / Codes

WALL MOUNT

27762



DOUBLE WALL MOUNT

## DOUBLE WALL MOUNT

Base parete per montaggio laterale di 2 dispositivi  
Wall base for side mount of 2 devices  
Support fixation en applique (à double filetage) pour 2 dispositifs

Codici / Codes

DOUBLE WALL MOUNT

27763

